

## *Required Installation Tools*

- Cordless drill
- Electric drill (preferably a hammer drill)
- Wrenches/ Sockets:
  - 7/16", 1/2", 9/16" sockets w/ ratchet
  - 7/16", 1/2", 9/16" combination wrenches
- Phillips and flat head screwdrivers
- Hacksaw with 18 tooth blade
- Drill bits:
  - 1/4", 5/32", 11/64"
  - 1/4" x 4" masonry bit
  - 1/4" x 6" masonry bit
  - 1/2" x 4" masonry bit
- #2 Phillips
- #3 Phillips
- 5/16" nut driver
- 7/16" socket driver
- Countersink
- Hammer
- 12" Torpedo level
- 1/2" round bastard file
- Wire strippers with cutters
- Circular saw or Jigsaw (cordless)
- 25 ft. tape measure
- 100 ft. tape measure
- 100 ft. string
- Flat shovel
- Box knife
- Scissors
- Extension cord (s)
- Broom or cordless vacuum
- 6-8 "C" clamps (undertrack installations only)
- Right angle drill (optional)
- Lighter or butane torch